



## Furby 2012 FAQs

### How do I turn Furby On/Off?

Similar to Furby 1.0, Furby Party Rockers do not have an on/off switch.

To turn it off try the following:

1. Place Furby in quiet room and do not play with it.
2. Remove the batteries.
3. Using the Furby App, put Furby to sleep (Lulla Baah feature).

### How do I install the batteries?

1. Loosen 2 screws using a phillips head screwdriver (cross) from the plastic base of Furby
2. Remove the base
3. Insert 4 AA alkaline batteries
4. Push the refresh button for 2 seconds
5. Replace base and tighten screws

### Where can I find the datecode on my Furby?

Furbys date code is in the form of a hot stamp. It is located inside the battery compartment, visible from the rear closest to the tail.

### There is a high pitched tone coming from Furby and/or my iOS device.

The noise you are hearing is how Furby communicates with the mobile device and other Furbys. Some people may hear it, others will not. Some animals may also hear the noise. Don't worry, the tone will not cause any harm to people or animals.

### I changed the batteries in my Furby to fresh/new alkaline batteries and it is still acting "weird". How do I fix it?

Remove the base of Furby and push the refresh button for 2 seconds, then replace the base. This will reset the hardware while retaining all of the personality data.

### My Furby fell asleep and I can't seem to wake him up.

Remove the base of Furby and push the refresh switch for 2 seconds, then replace the base. This will reset the hardware while retaining all of the personality data.





### **Furby Cleaning Instructions**

Gently brush your Furby's hair with a cloth or soft brush to loosen any dirt. Then use a SLIGHTLY damp cloth to remove any stains. DO NOT put in the washing machine, submerge in water or get Furby wet in any way other than using a slightly damp cloth. DO NOT use detergents or stain removers on the fur.

### **Where are Furby's Sensors?**

Furby is sensitive to touch, motion, sound, & other Furbys.

### **Can Furby Dance?**

Yes; Furby will dance to any type of music.

### **Why isn't Furby dancing when music is playing?**

Try a different song or turning up the volume on the the iPod.

### **Can Furby talk to other Furbys?**

Yes; Furby recognizes when other Furbys are present and will strike up conversation. If you get the right personalities in the right mood, you may even get them to sing to each other. Sometimes Furbys get along, sometimes they don't.

### **My Furby will not communicate with other Furbys.**

1. Be sure that both Furbys are facing each other
2. It is easy for Furby to be distracted, be sure that background noise is minimal

### **Does Furby respond differently depending on what I do?**

Yes; you can tickle, feed, pet, shake, hug, tilt, hold your Furby upside down, and pull its tail. Each interaction will effect the personality it becomes.

### **Does each color (or package) represent a different personality?**

No; all Furbys start out as the same personality. They develop distinct personalities based on how you play with them. Every Furby can become any personality.





**How many personalities does Furby have?**

You'll have to keep playing to find out.

**How do I get Furby to the personality that I want?**

All Furbys start out the same, but each Furby develops a personality based upon the way you play with it.

**What if I don't like the personality that my Furby has become?**

If you don't like the personality of your Furby, try treating it differently and see what personality develops.

**How much content is loaded into Furby?**

You'll have to keep playing to find out.

**Furby doesn't respond to my voice.**

1. When talking to Furby, be sure you are looking directly at him/her and speak slowly and clearly. The closer you are to Furby, the easier it is for him/her to hear you.
2. It is easy for Furby to be distracted, be sure there is minimal background noise

