


# Program-a-BOT™

## Package Contents:

- Program-a-BOT
- One Maxi Pals Robot
- Instruction manual



## Key Features:

- Program-a-BOT**
- 36 Programmable Actions
  - Sound Sensor & Intelligent Detect Obstacle Sensor
  - Communicates With His Robot Family
  - Motor Driven Performs Animation & Responsiveness

### Maxi Pals

- Wind Up & Release To Go
- Press The Button To Activate Light



## WARNING:

**CHOKING HAZARD – Small parts.  
Not for Children under 3 years.**

## Safety Precautions:

- Parents, this toy is recommended for children 5 years and older. To ensure that your child's play is both safe and fun, please review the operating instructions with your children. If toy is in the presence of children under 5 years of age, adult supervision is recommended.
- DO NOT pick up moving robot
- Keep hands, hair and loose clothing away from the tires and the wheel hubs when power switch is turned ON.
- DO NOT operate your robot on the street. Avoid hitting people, pets or furnishings. Recommended operation is on a clean, flat surface.


### Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Cautions:

- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

## Index To Parts:



## Battery Installation:

### Battery Requirement:

•Your Program-a-BOT is powered by 4 x "AA" size alkaline batteries (not included).

### Battery Installation : Program-a-BOT

1. Make sure the power switch is in "OFF" position (pic.1).
2. Use a Phillips head screwdriver to loosen the screw (turn counter-clockwise) on the 2 **Battery Compartments** located in BOTH LEGS (pic.2).
3. Insert 4 x "AA" size alkaline batteries with "+" and "-" signs as shown inside 2 **Battery Compartments** (pic.3 and pic.4).
4. Close the 2 **Battery Compartments** cover using a Phillips head screwdriver.




2 x 1.5V "AA" size  
alkaline batteries  
for Left Leg



2 x 1.5V "AA" size  
alkaline batteries  
for Right Leg

### Battery Installation: Maxi Pals (Included)

1. Battery compartment is located on the back of the robot.
2. Use the Phillips head screwdriver to loosen the screw (turn counter-clockwise) (pic.5).
3. Install 2 "LR44" button cell batteries. Align "+" and "-" sign as shown (pic.6).
4. Close the battery door and tighten the screw.



## Getting Started:

- Turn the "ON / OFF" switch to "ON" position to wake up Program-a-BOT and he will begin to move around.

## 1. Sound Detection:

- 1.1 Wait until Program-a-BOT stops moving.
- 1.2 Clap your hands or make a loud noise.
- 1.3 Program-a-BOT will respond with robotic sounds and actions.



| Clapping Position     | Robot Action |
|-----------------------|--------------|
| Clap to the Left      | Turn Left    |
| Clap to the Right     | Turn Right   |
| Clap in Front or Back | Move Forward |

## 2. Program Function:

- 2.1 Wait until Program-a-BOT stops moving.
- 2.2 Press any combination of action keys on the keypad (you can enter up to 36 actions in one run)
- 2.3 Press Go key to activate the robot.
- 2.4 Press the Go key again to stop Program-a-BOT.



### 3. Object Detection:

- 3.1 Program-a-BOT can automatically sense an obstacle in front of him while walking.  
3.2 Program-a-BOT will stop his movement and turn around to avoid an obstacle.



### 4. Room Guard Function:

- 4.1 Wait until Program-a-BOT stops moving.  
4.2 Press "Alert" key and his eyes will flash two times.  
Program-a-BOT will enter into Room Guard mode.  
4.3 Program-a-BOT will alert you with lights, movement and sounds when any object moves in front of him.  
4.4 Press the "Alert" key again to exit the Room Guard mode.

### 5. Interaction with Maxi Pals:



- 5.1 Program-a-BOT will interact with Maxi Pals (Included).  
5.2 Hold the Maxi Pals Robot near the IR communicator of Program-a-BOT.  
5.3 Press the button on the top of Maxi Pals to send a light signal.  
5.4 Program-a-BOT will respond and move.

| Light Signal      | Action       |
|-------------------|--------------|
| Press One Time    | Move Forward |
| Press Two Times   | Turn Left    |
| Press Three Times | Turn Right   |

### Communicates with His Robot Family

Robot Family Series1



### 6. IR Communication:

- 6.1 Program-a-BOTs love to talk to each other.  
If you and a friend have two or more Program-a-BOTs, you can get them to talk to each other.  
6.2 Face them together and no more than 2 feet apart for them to see and respond to each other.  
If they do not start talking to each other, try again.



Note: This illustration shows the maximum distance for Program-a-BOTs to communicate with each other or other Robot Family members.

### 7. Programming other Robots:

- 7.1 Program-a-BOT can program Echo-BOT and Jabber-BOT (not included).  
7.2 Wait until Program-a-BOT stops moving.  
7.3 Press any combination of action keys on the keypad.  
7.4 Press Go key TWO TIMES to activate the other robot.

### Hints to Play:

- Once Program-a-BOT is waiting for your commands, give the command in a clear sound. It is best to be between 1 and 3 feet away from Program-a-BOT when giving commands.
- It is important that the environment be fairly quite for Program-a-BOT. Surrounding noise will interfere with your commands.
- Operate only on flat, smooth (but not slippery), dry surfaces.
- Do not use Program-a-BOT in sand, water or snow. If your Program-a-BOT is trapped in a confined area for a long period of time, he will go to the Power Saver Mode.

### Trouble Shooting:

| Symptom  | Cause   | Correction  |
|--|---|---|
| Program-a-BOT does not move or runs slowly.      | <ul style="list-style-type: none"> <li>Loose battery connection.</li> <li>Main power switch is not in "ON" position.</li> <li>Batteries are not placed in compartment correctly.</li> <li>Batteries are exhausted.</li> </ul> | <ul style="list-style-type: none"> <li>Check battery connection.</li> <li>Switch on the power.</li> <li>Check the battery polarity.</li> <li>Replace all old batteries with new ones.</li> </ul>                          |
| Program-a-BOT does not react or Loss of control. | <ul style="list-style-type: none"> <li>Environment too noisy.</li> <li>Program-a-BOT moving or talking.</li> <li>Entered into Power Saver Mode</li> </ul>   | <ul style="list-style-type: none"> <li>Play in a quiet environment.</li> <li>Wait for Program-a-BOT to stand still &amp; command it again.</li> <li>Push ON / OFF switch off, then ON again to start the play.</li> </ul> |

Note: Program-a-BOT will automatically enter into Power Saver Mode after 5 minutes when not in use. To turn him on again, switch "ON / OFF" switch OFF and ON again to start the play.

### Care and Maintenance:

- This product is intended for indoor use only.
- Always remove batteries from the toy when it is not being used for a long period of time.
- Wipe the toy gently with a clean damp cloth.
- Keep the toy away from direct sunlight and/or direct heat.
- Do not immerse the toy into water that can damage the electronic assemblies.

### Notes:

- Parental guidance is recommended when installing or replacing batteries.
- New and alkaline batteries are recommended to be used in this toy to obtain best and maximum performance.
- You are advised to replace old batteries with new batteries as soon as the function becomes impaired.
- Users should keep and retain this information for future reference.
- Users should keep strict accordance with the manufacturer's instructions while operating the product.

### Battery Specification:

Program-a-BOT

- Power Supply:
- Rating: DC 6V 4W
- Batteries: 4 x 1.5V "AA"/LR6 / AM3
- Requires 4 "AA" size alkaline batteries (not included)

Maxi Pals

- Power Supply:
- Rating: DC 3V 0.06W
- Batteries: 2 x 1.5V "LR44" button cell batteries
- Requires 2 "LR44" button cell batteries (included)

Silverlit®

Silverlit Toys (U.S.A.) Inc. P.O. Box 90608, City of Industry, CA 91715-0608

©2002 Silverlit Toys Manufacturing Limited. All rights reserved.

Collect them All!

Robot Family Series2